

BOARDS FOR INTERACTIVE PROJECTORS

Electrically height adjustable board systems for interactive projectors

Pylon system for wall mounting for interactive pen-operable projectors

Pylon system for wall mounting for interactive finger-operable projectors



d¹³⁰ deluxe

Stroke
50 cm

Image shows:
EEB2013O with
Epson projector

For projector	Without projector	
	for pen touch	
Projection surface	2,07 x 1,30 m	1,92 x 1,20 m
Image size	2,07 x 1,30 m	1,92 x 1,20 m
Hitachi	EHI2013O ^{*1}	EHI1912O ^{*1}
Epson	EEB2013O ^{*2}	EEB1912O ^{*2}
Nec	ENE2013O ^{*3}	ENE1912O ^{*3}
Optoma	EBL2013O ^{*4}	EBL1912O ^{*4}
Boxlight Mimio P12	EBL2013O ^{*4}	EBL1912O ^{*4}
Eiki	EMP2013O ^{*5}	EMP1912O ^{*5}
Vivitek	EVI2013O ^{*6}	EVI1912O ^{*6}
Benq	EVI2013O ^{*6}	EVI1912O ^{*6}

- Electrically height adjustable systems with central telescopic pylon column and leveling feet for wall mounting
- Board frame: Black anodized
- Central surface: Matt white, can be written on and dry wiped, magnetic

^{*1} For use with Hitachi CP-TW3005, CP-TW2505
^{*2} For use with Epson EB-685WI, EB-675WI, EB-1440UI, EB-585WI, EB-575WI, EB-1420WI
^{*3} For use with Nec UM352Wi (Multi-Pen), UM351Wi (Multi-Pen), U321Hi (Multi-Pen), UM301Wi (Multi-Pen)

^{*4} For use with Optoma W319USTi, Boxlight Mimio P12BIW, P12LIW, P12LIH
^{*5} For use with Eiki EIP-WSS3100i
^{*6} For use with Vivitek D756USTi, DH759USTi, Benq MW855UST, MH856UST



With finger touch

Image shows:
EMPT1913O with Hitachi
projector and finger touch
module

Stroke
50 cm

For projector	Without projector
	for finger touch
Projection surface	1,92 x 1,30 m
Image size	1,92 x 1,20 m
Hitachi	EHIT1913PO ^{*1}
Nec	ENET1913PO ^{*2}
Optoma	EBLT1913PO ^{*3}
Boxlight Mimio P12	EBLT1913PO ^{*3}
Boxlight Mimio P10	EMPT1913PO ^{*4}
Vivitek	EVIT1913PO ^{*5}
Benq	EVIT1913PO ^{*5}
Projection surface	1,88 x 1,30 m
Image size	1,88 x 1,17 m
Epson	EEBT1813PO ^{*6}

OPTIONAL: Floor plate

- Steel, 0,8 cm thick
- Colour: RAL 9006 white aluminum
- Suitable for gypsum plasterboard wall mounting

Item no. **PSTSCETA**

^{*1} For use with Hitachi CP-TW3005, CP-TW2505
^{*2} For use with Nec UM352Wi (Multi-Touch), UM351Wi (Multi-Touch), UM351W, U321Hi (Multi-Touch), UM301Wi (Multi-Touch)
^{*3} For use with Optoma W319USTi, W320USTi, EH319USTi, EH320USTi, Boxlight Mimio P12BTW, P12LTW, P12LTH

^{*4} For use with Boxlight Mimio P10WX32NXT
^{*5} For use with Vivitek D756USTi, DH759USTi, Benq MW855UST, MH856UST
^{*6} For use with Epson EB-696UI, EB-695WI, EB-680WI, EB-1460UI, EB-1450UI, EB-1430WI, EB-595WI